



TIMBERBITS

HELPING YOU CREATE WITH WOOD

Panama Pen

Drill Bit required – 10.3mm or 13/32”

Bushings required – Bushings - Panama (Code: A0079)

Assembly

Layout the parts as shown below (Figure 1).

1. Press the Nib Coupler into the Brass Tube.
2. Click Mechanism – unscrew the Cap from the Housing (Figure 2). Remove the Spring from the Housing.
3. Place clip on the Housing.
4. Press the Housing into the other side of the Brass Tube.
5. Slide Parker Refill into the brass tube from the nib end then screw the Cap back into the Housing after putting the spring into place.
6. Screw the Nib Assembly on the Nib Coupler

Figure 1



Figure 2

