

Hour Glass Pen Kit

Drill Bit required – 10.5mm and 12.5mm"

Bushings required – Bushing - Hour Glass (Code: A0237)

Turning Diameters



Turn outside diameter of the pen blank down to dimensions above.

Please note that these dimensions are only recommendations. You should check the diameter of the kit with a set of digital callipers and work out the dimensions that you think works best for you.

Assembly

Layout the parts as shown below.

1. Press the Nib Coupler (might be screwed onto the centreband in the packet) onto the Long Tube then press the end cap onto the other end.
2. Press the Lid cap onto the short tube then press the centerband onto the other end.
3. Insert the Spring into the long barrel through the nib coupler then slide the rollerball into after the spring.
4. Screw the nib onto the Nib Coupler then screw the long and short tubes together to finish the pen.

