

Panama Pen

Drill Bit required – 10mm (really tight fit) or 13/32"

Bushings required – Bushings - Panama (Code: A0079)

Assembly

Layout the parts as shown below (Figure 1).

1. Press the Nib Coupler into the Brass Tube.
2. Nib Assembly – unscrew the Nib from the Male Thread (Figure 2). Remove the Stylus Tip from the Male Thread.
3. Press the Male Thread into the Nib Coupler.
4. Click Mechanism – unscrew the Cap from the Housing (Figure 2). Remove the Spring from the Housing.
5. Place clip on the Housing. Press the Housing into the other side of the Brass Tube.
6. Slide Parker Refill into the brass tube from the nib end then screw the Cap back into the Housing after putting the spring into place.
7. Place the Stylus Tip back onto the Male Thread then screw Nib back onto Male Thread. Screw the Nib Assembly on the Nib Coupler

Figure 1




Figure 2

