



TIMBERBITS

HELPING YOU CREATE WITH WOOD

Letter Opener Kit

Drill Bit required – 7mm

Bushings required – Bushing – Letter Opener (Code: A0251)

Turning Diameters

You do not need specialised bushings for this kit. All you need is a set of callipers to guide you. Finished diameters of 11mm to 13mm generally looks good on this kit, but use your creativity to turn out something original

Assembly

1. The Blade Assembly is shipped already assembled.
2. Disassemble the Blade Assembly into its 3 components (Blade, Blade Stiffener and Blade Coupler).
3. Push the Blade Coupler onto the Brass Tube.
4. Push the End Cap onto the other side of the Brass Tube.
5. Slide the Blade Stiffener onto the Blade.
6. Screw the Blade into the Blade Coupler.

