



TIMBERBITS

HELPING YOU CREATE WITH WOOD

Slimline Pencil Pen Kit

Drill Bit required –7mm

Bushings required – Bushing - Slimline (Code: A0023)

Assembly

1. Place the blank on the mandrel with the bushes in each end.
2. Turn the blank to the top diameter of the bushes.
3. Finish the blank with your choice of finish.
4. Layout the parts as shown below.
5. Push the Nib Coupler onto the lower brass tube.
6. Slide the clip onto the clip coupler then press the clip coupler onto the upper brass tube.
7. Press both brass tubes on the Center Band.
8. Slide the Pencil Mechanism into the barrels from the clip coupler end then screw the nib onto the nib end of the pencil mechanism.
9. Slide the End cap over the eraser end of the pencil mechanism.
10. Push the End Cap down and release to advance the lead.

